



www.facebook.com/AKBlasterMOD
Online Store: www.ak-blastermud.com
email: akblastermud@gmail.com
Address: Room 1203, 29 Wing Hong Street, Hong Kong
WWW.AK-BLASTERMOD.COM

PUMP KIT FOR LONG SHOT BLASTER



PASSION FOR THE DARTS



WORKER

F10555



**AK
HOMME**

X.S.W

ML3D

AK-BLASTER MOD SHOP IS AN ONLINE SHOP AND WE MAKE PRODUCTS TO MODIFY AND CUSTOMIZE NERF BLASTER. WE OFFER WORKER MOD, F10555, MEN-GUN MOD, AK TACTICAL GEAR.XSW.ML3D, ARTIFACT, ETC BRAND PRODUCTS ON BLASTER MODDING. WE PROVIDE SERVICES ON CUSTOMIZE BLASTER WITH PARTS, 3D PRINTING AND PAINT WORKS. WE ORGANIZE BLASTER GAME ACTIVITIES AND NERF PARTY FOR KIDS. WE OFFER VENUE DESIGN, CUSTOMIZE INVITATION CARDS, HEALTHY FOODS AND CAKE, ORGANIZE NERF BATTLE GAME AND PHOTOGRAPHY SERVICES.

Disclaimer

Disclaimer:

Individual results may vary. Modding blasters is a hobby of ours, and in no way do we claim to be experts on the subject. We've written this manual for other enthusiasts who want to accomplish what we have with our blasters. However, due to legal reasons, we're unable to guarantee any results and the content in this manual should not be considered professional advice.

The use of this information and recommended products should be based on your own due diligence. You agree not to hold the authors and/or distributors of this manual liable for any success or failure of your endeavors that are directly or indirectly related to the purchase and use of our information, recommended products and services.



Make sure you have good knowledge on electric circuit and modding skill. Please read below instruction carefully and reference to online video on installing instruction.

INSTALLATION STEPS

Supplies Needed:

- Small Phillips Head Screwdriver
- Small Flat Head Screwdriver

Step 1:

Remove all the screw on the blaster and separate into 2 halves, cut and remove the area shown in green boxes.



Step 2:

Polish the cut edge to remove any flash remains, make reference to below image of finished cutting.

**Step 3:**

Install the pump kit slider under the barrel jacket, notice the direction and remove the tape sheet.



Step 4:

Simply stick the slider parts under the barrel jacket, make reference to below image of finished installation.



Step 5:

Install the metal rods on the hand pump part and then to the slider, make sure all the screws are fasten as marked red circles.



Step 6:

Test whether the pump parts goes smooth on the slider, plug the nuts to connect the metal rods with the blaster body. Secure the nut and get ready for battle!

