

# HAMMERSHOT



PASSION FOR THE DARTS



**WORKER**

**F10555**



**AK  
HOMME**

**X.S.W**

**ML3D**

AK-BLASTER MOD SHOP IS AN ONLINE SHOP AND WE MAKE PRODUCTS TO MODIFY AND CUSTOMIZE NERF BLASTER. WE OFFER WORKER MOD, F10555, MEN-GUN MOD, AK TACTICAL GEAR.XSW.ML3D, ARTIFACT, ETC BRAND PRODUCTS ON BLASTER MODDING. WE PROVIDE SERVICES ON CUSTOMIZE BLASTER WITH PARTS, 3D PRINTING AND PAINT WORKS. WE ORGANIZE BLASTER GAME ACTIVITIES AND NERF PARTY FOR KIDS. WE OFFER VENUE DESIGN, CUSTOMIZE INVITATION CARDS, HEALTHY FOODS AND CAKE, ORGANIZE NERF BATTLE GAME AND PHOTOGRAPHY SERVICES.

# ***Disclaimer***

---

## **Disclaimer:**

Individual results may vary. Modding blasters is a hobby of ours, and in no way do we claim to be experts on the subject. We've written this manual for other enthusiasts who want to accomplish what we have with our blasters. However, due to legal reasons, we're unable to guarantee any results and the content in this manual should not be considered professional advice.

The use of this information and recommended products should be based on your own due diligence. You agree not to hold the authors and/or distributors of this manual liable for any success or failure of your endeavors that are directly or indirectly related to the purchase and use of our information, recommended products and services.



Make sure you have good knowledge on electric circuit and modding skill. Please read below instruction carefully and reference to online video on installing instruction.

## ***INSTALLATION STEPS***

---

### **Supplies Needed:**

- Small Phillips Head Screwdriver
- Small Flat Head Screwdriver

**Step 1: Insert the brass tube to the corresponding location on the cylinder base. A small hammer could help fixing the tube to just fitting holes.**



1.将铜管插入卡位里，如偏紧用工具轻敲一下



**Step 2: Wear the cylinder fixtures in between each brass tube, fit the knot to the base as shown in red circle and red dot.**



**Step 3: Wear the cylinder top cover onto the cylinder. Grip the brass tube together in order to insert the top cover to the brass tube in correct position.**



Step 4: In case there are difficulty to wear the cover, make use of a cutting to trim the inside circumference as shown in red circles.



Step 5: Disable the Air Resistor insert the plunger, by damaging the parts or simply apply instant glue to set it at open condition permanently. Replace the stock foam pad with the pad in the kit.





Step 6: Replace the cylinder gear and front fixture with the white printed parts in the kit. Secure all the module and close the blaster.

4. 根据箭头指示位置安装转鼓和齿轮，安装好后盖上外壳 完成。

