Buffer Tube

Red Circle: Remove the screw holding columm



Yellow Circle: Trim and remove the column



Yellow Circle: Trim and remove the column

Install the spring containing block into the buffer tube